



calomax

INSTALLATION, OPERATION AND SERVICING INSTRUCTIONS FOR THE ECLIPSE PUSH BUTTON WATER BOILERS



**MADE IN
BRITAIN**



Issue 14
18/06/25
DCR: 1171



Please read these
instructions carefully
before operating your
boiler for the first time

Calomax Limited
Lupton Avenue, Leeds LS9 7DD
Tel. 0113 249 6681
email: service@calomax.co.uk www.calomax.co.uk

CONTENTS	PAGE
INTRODUCTION	3
CHECK LIST	3
APPROVALS	3
CONSTRUCTION	4
INSTALLATION	4
LOCATION	4
COLD WATER INLET	5
ACCESS INSTRUCTIONS	6
VENT / OVERFLOW	7
ELECTRICAL CONNECTIONS	8
USER INSTRUCTIONS	8
SCALE	9
CLEANING	9
GENERAL OPERATION	10
TROUBLE SHOOTING	10
ACCESSORIES	11
SPARE PARTS	12/13
EXPLODED DIAGRAM	14/15/16/17
SERVICE INSTRUCTIONS	18/19
ROUTINE MAINTENANCE / ANNUAL INSPECTION	20
GENERAL FUNCTION	21
WIRING DIAGRAM	22
DIMENSIONS AND WEIGHTS	23
WARRANTY	24
PRODUCT SPECIFICATION	25

INTRODUCTION

Thank you for purchasing a boiler from the Calomax Eclipse range. All our products are designed to give years of simple, reliable operation. To ensure this, it is important that the installation and subsequent servicing and maintenance is carried out by a suitably qualified person in accordance with these instructions.

For assistance in finding a suitable engineer in your area, visit our website www.calomax.co.uk, contact our service department on 0113 249 6681 or email: service@calomax.co.uk

CHECK LIST counter top models

Before commencing installation, check that the following parts have been supplied with the boiler:

1. WRAS approved flexible water inlet hose suitable for potable water.
2. Drip tray kit

CHECK LIST wall mounted models

Before commencing installation, check that the following parts have been supplied with the boiler:

1. Wall mounting bracket

APPROVALS



This product conforms to the CE and UKCA marking directive through compliance with the following standards:

- The Low Voltage Directive 73/23/EEC
- The Electromagnetic Compatibility Directive 89/336/EEC

Compliance with these standards has been confirmed through testing by an independent NAMAS approved body.

Any water fittings or water-using appliance connected to the mains water supply must comply with the Water Fittings Regulations (or Byelaws in Scotland). This ensures the appliance does not waste or contaminate the drinking water supply. In order to demonstrate compliance, this product has been submitted to the Water Regulation Advisory Scheme (WRAS) and proven to conform to these regulations.



The drip tray (part ref: EDTKKB where supplied) has been treated with an antimicrobial additive and independently tested to prove the effectiveness of the surface hygiene.


CONSTRUCTION

All metallic components of the machine, in direct contact with drinking water are manufactured from high quality 316 grade stainless steel, or non-ferrous materials, providing maximum resistance to corrosion.

INSTALLATION AND MAINTENANCE

LOCATION

The boiler must be installed in a location where access is restricted to operators who are suitably trained, or where untrained operators of the machine can be supervised by trained personnel.




To comply with recommendations from the Health and Safety Executive it is important that due consideration be given to safe operation of the controls of the boiler. The boiler should therefore be mounted in such a manner that the operator can stand directly facing the machine with the controls at a recommended height from the floor to the draw-off tap handle of 1200mm +/- 100mm. Consideration should also be given to the servicing requirements of the machine.

The maximum and minimum ambient operating conditions must be between 35°C and 5°C. The appliance is not suitable for installation where a water jet could be used. Install the boiler on a surface or wall suitable for the working weight of the boiler. Allow clearance for ventilation and for the easy removal of the outer casing lid and front panel. Calomax recommend a minimum clearance of 50mm on all sides of the boiler. A suitably qualified engineer must install this unit. Plumbing and electrical installation work may be involved.


WALL-MOUNTED BOILERS ONLY

Hang the boiler on the wall bracket and secure into place with 4th fixing. The electrical cable should be routed as shown. The use of 6mm Rawl-Bolts is recommended to secure the bracket to a wall of appropriate construction to support the working weight of the boiler.



3 point fixing wall bracket
for wall mounted range

The water inlet fittings are designed for push-fit connections. Compression fittings can be used if preferred but these should be connected directly to the copper pipe (not the plastic push-fit) using the Ø12-15mm compression reducing sets supplied.



COLD WATER INLET

The boiler must be connected to a potable water supply using the food grade hose where provided, or rigid 15mm pipe in a manner which complies with UK water regulations via an appropriate isolating valve. Always use the new hose supplied (counter-top models only). Do not reuse old hoses. The supply must provide a constant pressure of between 20 KPa and 1000 KPa (0.2 to 10 Bar).


If the water supply contains excessive solids in suspension it is recommended that a fine mesh "in line" water filter is fitted in the pipe work. Failures due to scale and sediment are not covered by the warranty.

TO COMPLY WITH UK WATER SUPPLY REGULATIONS A SINGLE CHECK VALVE MUST BE FITTED.

BEFORE CONNECTING, THE SUPPLY PIPE MUST BE THOROUGHLY FLUSHED OUT TO ENSURE THAT FOREIGN MATTER DOES NOT BLOCK OR ENTER THE SOLENOID VALVE


ACCESS INSTRUCTIONS

Access to the internals of the machine is gained by the removal of the front panel. Prise off the outercasing lid from its mounting clips. remove the top two panel mounting screws. The front panel can now be removed by prising off the remaining two retaining clips at the bottom of the panel.



VENT & OVERFLOW

The vent / overflow pipe must be extended and laid with a **continuous fall**, discharging to a safe and visible point. The pipe should not be directly connected to a closed waste, as taste problems may occur and should never be allowed to become blocked or restricted. 15mm copper or 'Speedfit' pipe should be used. The drip tray kit provided with the counter top models allows the option of plumbing the overflow pipe to discharge into the drip tray and then plumbing the drip tray to a safe and visible point of discharge. If the machine is operated without the overfill pipe being extended as advised, any subsequent damage incurred will be the responsibility of the installer.



If the boiler is required to drip or overflow into the drip tray, the configuration of pipework may be altered as follows. Remove the machine front panel and unclip the pipework elbow. Carefully pull the elbow in the direction of the arrow, out of the silicone connecting tube on the end of the main water pipe. The silicone connecting tube will now direct water into the drip tray.

ELECTRICAL CONNECTIONS

The boiler should be connected to a 240V ac 13A electrical supply, capable of carrying a load of 3kW. The installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable.

If an Arc Fault Detection Device (AFDD) is in circuit, we advise using a 'C-curve' variant and ensuring the firmware is kept up to date.

USER INSTRUCTIONS



During normal operation some external parts will become very hot. Care must be taken to avoid injury, a burn or scald.

This equipment is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.


Children should **NOT** be allowed to play or use this appliance.

In the event of the power supply lead to the boiler becoming damaged, the appliance must be removed from service. A replacement genuine part is available from Calomax Ltd, and must be fitted by a suitably qualified engineer.

COMISSIONING

Turn on the water supply and then switch on the electrical supply. When the power switch is pressed on the front fascia the Wait light will illuminate and the unit will fill with water (1.3 L/Min). When water reaches the low water level sensor, the element will be energised and the solenoid will continue to fill the boiler to the normal operating water level. When the water has reached the normal operating temperature, the Wait light will extinguish and the Ready light will illuminate. At this time the dispense button will be energised.

SUBSEQUENT USE

After the boiler has finished the commissioning cycle, and water is dispensed from the boiler, water will be replenished in short cycles (small amount of water and then heat). The solenoid and element will never be on at the same time unless the boiler is switched off and on again (re-setting commission mode). In normal use the boiler will always be at operating temperature indicated by the Ready light being illuminated. The full light will be illuminated only when the boiler is full of boiling water. By pressing the symbol  on the upper fascia label, the economy feature is selected. This feature reduces the working capacity of the appliance by approximately half. The Full light will be disabled and the eco light illuminated.

SCALE

The production of scale is a natural phenomenon and commonly occurs in hot water systems. The nature of the scale produced and its rate of formation varies widely throughout the country.

To ensure continuous, reliable operation, the boiler should be regularly de-scaled by a suitably qualified engineer.

The Eclipse boiler benefits from an integral scale inhibitor. **This is not** a scale eliminator and its effects will differ according to the water quality in your area. To ensure trouble free operation, periodically check for scale inside the boiling chamber. De-scaling may be required within the first 12 months. This is not covered under the product's warranty as it is not a fault.

CLEANING



Avoid using any abrasive materials. Wiping the outer casing with a damp cloth should be sufficient. Some stainless steel cleaning products may not be suitable for plastic and must not come in contact with the plastic fascia parts. Always disconnect the electrical supply before cleaning. **Never use a spray jet or any other method that could cause water to enter the electrical chamber.**

GENERAL OPERATION

- Hold a cup below the dispense nozzle or place large vessels on the drip tray. Care must be taken to avoid injury through splashing or over-filling.
- To begin filling, press the dispense button – hot water begins to flow.
- To stop filling, release the button .

BASIC TROUBLE SHOOTING


Symptoms	Possible Cause	Remedy
No boiling water available	Faulty dispense valve	Replace valve
	Element failed or tripped	Replace element or reset
	Defective Printed Circuit Board	Replace Circuit Board
Overboiling	Excessive internal scale. (See 'De-Scale' page 19)	De-scale the boiler (Particularly thermistor)
	Faulty wiring to thermistor / faulty thermistor	Repair / replace as required
	Temperature controller needs adjusting	Reduce operating temperature
	Element failed to earth	Replace element
	Defective Printed Circuit Board	Replace Circuit Board
Overflows	Dirt in solenoid valve.	Clean solenoid filter or replace solenoid, "work the boiler" - see Service Instructions.
	Level sensors require de-scaling or replacing	De-scale / replace sensors
	Defective Printed Circuit Board	Replace Circuit board

ELEMENT THERMAL CUTOUT

The Eclipse range of boilers has an inbuilt thermal cutout device to protect the element in a boil dry situation. Should the cutout be activated, contact an approved Calomax service provider for advice.

ACCESSORIES

Accessories



Securing clamp kit

(Counter-top models only)

Ref. MFK



Fused spur time switch

Ref. 7DFST


Max 3 kW



Plug-in time switch

Ref. 7DPIT


Max 3 kW



Water filter kit

(To reduce taste & odour problems)

Ref. CWFK




Filter Cartridge


(Replacement filter for kit shown above)

Ref. CWFC1


Spare parts are usually available ex-stock.
Please quote Model & Serial Number.




EPBPCBT
ECLIPSE P.C.B.




ELPCBT
ECLIPSE LIGHT PCB




E3BRK
ELEMENT 3kW
RESET KIT




ETAK
ECLIPSE
THERMISTOR
ASSEMBLY KIT




EPBSV
SOLENOID VALVE




MBLG1
BODY LID GASKET
FOR PB3C10
MODEL




MBLG2
BODY LID GASKET
FOR PB3W5 MODEL




X8 various
sizes
ESSK
ECLIPSE SILICONE
SEAL KIT



PS
POWER SWITCH




ELPK
ECLIPSE LEVEL
PROBES KIT




NBPRG
BODY LID GROMMET




WIH2MK (2m)
WATER INLET
HOSE




WIHK (1m)
WATER INLET
HOSE




ESLM
KEY SWITCH
(INCLUDES 2 KEYS)



PBDVK
DISPENSE
SOLENOID VALVE




PBSAK
PUSH BUTTON
SWITCH




SPARE KEYS (x2)
FOR ESLM

Exploded parts view for Eclipse Push Button wall mounted boilers

(To be read in conjunction with the spare parts list)




* Complete set of 8 seals (2 sizes)



If parts required are not identified, please contact Calomax Limited


Exploded parts view for Eclipse Counter Top Models.

(To be read in conjunction with the spare parts list)



* Complete set of 8 seals (2 sizes)

If parts required are not identified, please contact Calomax Limited



SERVICE INSTRUCTIONS

When a solid red service indicator light on the front of the boiler is illuminated, the machine has been starved of water in excess of 20 minutes and the solenoid valve has been disabled to prevent damage to the solenoid coil through overheating. To re-energise the solenoid, the unit must be disconnected from the electrical supply and then switched back on, after first reinstating the water supply.

If the unit requires servicing the red service indicator will flash a sequence of light pulses. A 2x or 3x-light pulse generally indicates that the low or normal level probes require de-scaling.

A 4x-light pulse means the water level has reached the high level sensor and the likelihood is that the normal level sensor requires de-scaling, or the machine has over-filled due to debris trapped in the solenoid valve. The debris can be removed by drawing plenty of water from the dispense nozzle, causing the solenoid valve to operate and flush out the obstruction. The machine will reset itself once the problem has cleared. If this does not rectify the problem, turn off the water supply and check for debris in the solenoid valve filter. The unit can be used normally while the service indicator is flashing a 4x pulse. For further assistance, contact our service department on 0113 249 6681, email service@calomax.co.uk or find a local service engineer at www.calomax.co.uk

Access to internal components can be gained by the removal of the outer casing lid and front panel. Once the outer casing is removed, access to the Service Area has been gained. This access must be restricted to persons having knowledge and practical experience of the appliance, in particular as far as safety and hygiene are concerned.

DE-SCALE

ENSURE THE UNIT IS SWITCHED OFF AND UNPLUGGED.

To gain access to internals of the water tank, the body lid must be removed. Remove the 4 screws, break the lid gasket seal and lift it clear of the body.

Note: Whenever the body lid has been removed from the boiler a new lid gasket may be required to ensure a steam-tight joint. Damage to the unit caused by a poor lid seal is not covered by warranty.

Scale deposits should be removed from all internal surfaces, particularly the heating element, thermistor and level sensors by gently tapping or scraping. If the deposits are soft, use a nylon pad and flush out. Abrasive cleaning materials containing scouring powders and detergents must not be used, such materials can cause taste problems.

The integral scale-inhibitor of every Calomax boiler allows for a manual / chemical-free descale. Caustic chemical de-scalents should not be used.

IMPORTANT Before re-commissioning the boiler it is important that all scale and moisture is removed from the level sensors and insulating gaskets, to avoid a false signal being transmitted through the scale. Failure to remove this scale and/or moisture will cause the sensor to indicate to the PCB that water is covering the element, whether or not water is present. In this situation the PCB will energise the element causing failure. If in doubt, protect the element by hand filling with water to cover the element before switching on the electrical supply to the boiler.

ROUTINE MAINTENANCE / ANNUAL INSPECTION

Calomax boilers are designed to produce boiling water 24/7 and regularly maintained and serviced / de-scaled, we would expect them to last 10 years.

In hard water areas, the boiler may need to be de-scaled every 12 months, possibly even every 6 or 3 months. Boilers in soft water areas may never need to be descaled. You can find out how hard the water in your area is on the Calomax website under Support > Water Filter Advice.

Because our boilers last such a long time (20 years is not uncommon) it is important that they are inspected every 12 months, and the following routine checks carried out:

- 1. Check and de-scale where appropriate the tank, sensors and tap nozzles.**
- 2. Check the condition of the gaskets, washers and grommets; replace as appropriate.**
- 3. Check the condition of the wiring and the connections, including the plug and lead for counter-top boilers.**
- 4. Check the integrity of the element.**
- 5. Look for any leaks.**
- 6. Ensure that the tap bonnet is not over-tightened.**
- 7. For counter-top boilers check that the flexible hose is WRAS approved and that it is in good condition. Check wall mounted boilers to ensure that compression and push-fit connectors have not been mixed.**
- 8. If an inline water filter is fitted, check when the cartridge was last replaced.**

GENERAL FUNCTION

The printed circuit board (PCB) controls the heating and filling functions of the boiler by monitoring the thermistor and level sensors. The PCB also controls the external light unit to indicate the current state of the boiler. Red and yellow LED'S on the circuit board indicate whether the PCB has energised the element or solenoid respectively.

Should an element fail and need to be replaced, it may be necessary to replace the lid gasket to ensure a reliable steam-tight seal. **Note: the element has a permanent 'Live' feed, and the 'Neutral' is switched.**

PRINTED CIRCUIT BOARD (PCB)

In the unlikely event of a PCB failing and a replacement being required, full instructions will be supplied. It is important to note however, that the Triac PCB must be securely mounted against the copper heat-sink to ensure reliable heat dissipation. Heat transfer compound is also supplied with all replacement circuit boards.

ADJUSTING THE WATER TEMPREATURE SET POINT



The temperature potentiometer (Pot) is pre-set at Calomax and will only require adjustment in exceptional circumstances. Contact Calomax for advice.

NOTE: Tuning the temperature of push button boilers higher than the factory set temperature of 90°C will invalidate the WRAS approval.




Page 22




DIMENSIONS AND WEIGHTS



MODEL	PB3C10
Height (mm)	570
Depth (mm)	355
Width (mm)	240
Drip tray clearance (mm)	150
Working weight (Kg)	30.5



MODEL	PB3W5
Height (mm)	510
Depth (mm)	270
Width (mm)	240
Working weight (Kg)	21



WARRANTY GUARANTEE (UK Mainland customers only)

Calomax have manufactured water boilers in the UK for over 70 years. We are proud of our products and the back-up service we provide.

Properly maintained and serviced, a Calomax boiler should last many years and we have no hesitation in providing a 2 year warranty.

Some factors are beyond our control and would invalidate the warranty offered. These include:

- Incorrect installation.
- High / Low water pressure.
- Incorrect voltage supply.
- Accidental damage.
- Limescale build-up.

The last item can be a particular problem for water dispensing equipment in hard-water areas. All hot water equipment should be serviced and de-scaled by appropriate personnel on a regular basis to avoid a damaging build-up of limescale.

Although our boilers incorporate scale-inhibitor technology, we recommend that a taste, odour and scale filter should be fitted where appropriate.

Please visit our website www.calomax.co.uk for details of our Service Partner Network and the range of filters and accessories available.

PLEASE ENTER MODEL & SERIAL NUMBER FOR FUTURE REFERENCE

Model		
Serial Number		
Draw off Capacity	PB3C10 PB3W5	10 Litres 5 Litres
Heat-up Time (First fill to full capacity)	PB3C10 PB3W5	34 Minutes 21 Minutes
Voltage		220 - 240 V ac 50-60 Hz
Power rating	All Models	3kW (MAX)

Note: All measurements are approximate

PLEASE CONTACT OUR SERVICE DEPARTMENT FOR ASSISTANCE

Calomax Limited, Lupton Avenue, Leeds LS9 7DD

Tel: 0113 249 6681

email: service@calomax.co.uk



Calomax Limited
Lupton Avenue
Leeds
LS9 7DD

Tel. 0113 249 6681
email: service@calomax.co.uk
www.calomax.co.uk